


How to upgrade firmware & boot code on Cisco Small Business Switches

Review Cisco firmware release notes. If you have an older firmware you have to first upgrade to a somewhat newer firmware first before you can upgrade to the latest firmware. Normally if you have to do this, you also have to upgrade the boot code.

Firmware Upgrade Steps:

1. Download the firmware from Cisco's website and unzip the file
2. Login to the switch and go to "Administration" / "Upgrade/Backup Firmware"

3. Select these options:



Upgrade/Backup Firmware/Language

Transfer Method: via TFTP
 via HTTP/HTTPS
 via SCP (Over SSH)

Save Action: Upgrade Backup

File Type: Firmware Image
 Boot Code
 Language File

File Name: No file selected.

4. Select "Browse" and find the firmware file you downloaded

5. Click on Apply.

6. Once the upload is done, and IF you have a flashing red "x" at the top right by the word "cisco" click on it so you can save your config

7. Reboot the switch. If you are doing a constant ping to monitor it, you will lose about 20 to 25 pings while it reboots

8. Login to switch and verify the firmware version is correct.

Â

Boot Code Upgrade Steps:

1. Download the firmware from Cisco's website and unzip the file
2. Login to the switch and go to "Administration" / "Upgrade/Backup Firmware"

3. Select these options:

Upgrade/Backup Firmware/Language

Transfer Method: via TFTP
 via HTTP/HTTPS
 via SCP (Over SSH)

Save Action: Upgrade Backup

File Type: Firmware Image
 Boot Code
 Language File

TFTP Server Definition: By IP address By name

IP Version: Version 6 Version 4

IPv6 Address Type: Link Local Global

Link Local Interface:

* TFTP Server IP Address/Name:

* Source File Name: (0/160 characters used)

4. Type in the IP address of your TFTP server and the file name of the boot code file

5. Click Apply

6. Once the upload is done, and IF you have a flashing red "x" at the top right by the word "cisco" click on it so you can save your config

7. Reboot the switch. If you are doing a constant ping to monitor it, you will lose about 20 to 25 pings while it reboots

8. Login to switch and verify the firmware version is correct.

A

Online URL: <https://kb.naturalnetworks.com/article.php?id=203>