Tips for working with Cisco SPA5xx IP Phones

To reboot a phone via a web browser:

http://{ip address}/admin/reboot

To provision a phone via a web browser:

http://{ip address}/admin/resync?http://{ip address}/$MA.xml

Note: $MA is a Cisco variable for the MAC address of the phone.

To provision view the phone's current config (XML format):

http://{ip address}/admin/spacfg.xml

Online URL: https://kb.naturalnetworks.com/article.php?id=285