

# How to setup cell phone notification for new voicemail messages

When someone leaves you a message on your office voicemail, the phone system can call your cell phone, or any other phone number, to let you know you have a new message. This feature is enable and configured per station. There are two steps to setup this feature.

1. Turn on the "Outbound Notify" feature by following these steps:
  1. With your phone hung-up, press TRANS/PGM
  2. Dial 68
  3. Dial 1 to turn the feature on or 0 to turn it off
  4. Press HOLD/SAVE
2. Enter your cell phone number that you would like the system to call
  1. With your phone hung-up, press TRANS/PGM
  2. Dial 69
  3. Type in your telephone number
  4. Press HOLD/SAVE

Online URL: <https://kb.naturalnetworks.com/article.php?id=41>