How to setup cell phone notification for new voicemail messages

When someone leaves you a message on your office voicemail, the phone system can call your cell phone, or any other phone number, to let you know you have a new message. This feature is enable and configured per station. There are two steps to setup this feature.

- 1. Turn on the "Outbound Notify" feature by following these steps:
 - 1. With your phone hung-up, press TRANS/PGM
 - 2. Dial 68
 - 3. Dial 1 to turn the feature on or 0 to turn it off
 - 4. Press HOLD/SAVE
- 2. Enter your cell phone number that you would like the system to call
 - 1. With your phone hung-up, press TRANS/PGM
 - 2. Dial 69
 - 3. Type in your telephone number
 - 4. Press HOLD/SAVE

Online URL: https://kb.naturalnetworks.com/article.php?id=41